



SIGNFRAME KIT CONTAINS:
 1 SIGNFRAME WITH 3 SECURING CLIPS

STEP-BY-STEP INSTRUCTIONS:

- 1 Tip the signframe and insert the two hooks under rim, on short end of bin with pre-drilled holes. Align the signframe and container hole by pushing signframe upward. (FIG. 1)
- 2 After signframe and container holes are aligned, insert the securing clips from inside the container pushing through into the signframe holes. (FIG. 2)
- 3 Slide 8.5" x 11" sign with clear protector sheet through top slot of the signframe. (FIG. 3)

